


**TECHNICAL NOTE 06-01**  
**WATER RESTRAINT SYSTEM (WRS)**  
**Applying Target To HWRS Screen**  
Dated: May 3, 2001

**Introduction**

The following information is provided to help in aligning camera with the image. The target adheres best in warm temperatures (70° F).

**Description**

1. Start the Water Restraint System (WRS).
2. Align camera with the image as close to the center of the screen as possible.
3. Fire the system.
4. With an erasable ink marker, place a mark in the center of the firing area on the screen.
5. Remove the clear paper covering from the target.
6. Center the target, paper side up, over the mark on the screen. Align the target with notches at top, bottom, left and right as shown below:



7. With a hard object such as the bottom end of a pen or pencil, burnish all parts of the target. Press firmly but not hard enough to move the target or tear the paper.
8. Carefully, ROLL the paper back from one edge, over the target and off. Be very careful not to lift or stretch the vinyl target.